iClean® FLO3

IMPORTANT SAFETY INSTRUCTIONS. READ THESE INSTRUCTIONS COMPLETELY BEFORE USE. SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.


Applications & Model #s

Faucets (LQFC510) Ice Machines (LQFC520) Beverage Lines (LQFC530) Laundry (LQFC540)


Included with Purchase








Sediment Filter x1 (Inside Filter Housing)




User Guide x1




Filter Housing Wrench x1




Spare Part For Future Replacement: O-Ring x1



Mounting Bracket x1



3/8" Push-fit Connector x2



Power Adapter x1

Specifications

Model Number	LQFC5XX
EPA Establishment #	93508-CHN-1
Dimension	131 x 104 x 175 mm
Net Weight	530 g
Power Supply	AC 100-240 V, 50/60 Hz (100 W)
Water Line Connection	½" BSPP threaded to ¾" push fit
Water Pressure	0.02 MPa - 0.40 MPa
Flow Rate	1.0 - 8.0 L/min
Ozone Concentration	0.5 - 1.7 ppm
Tap Water Quality	Clean, TDS 60-200 ppm
Water Temperature	4-40 °C

Important Safeguards

- Read and follow this User Manual before installation, maintenance, and use. Failure to do so could result in injury, death, damage, and voided warranty.
- · Tighten filter housing when in use.
- Disconnect electrical circuits before installing/servicing.
- · Do not immerse power cord in water/liquid.
- Do not install device near burners, heaters, or cooking appliances.
- Install all plumbing connections before plugging power
- Never disassemble, repair, or customize the device; a certified technician must perform all repairs.
- Do not operate device if damaged/malfunctioning; unplug and call the manufacturer.
- Install over drain.
- Indoor use only.
- For more safety info, visit www.tersano.com.


Limited Warranty is valid for one year from the date of your purchase of the product as shown by the sales receipt. Details on website: www.tersano.com.

tersano

For more information, contact tersano: (800).727.8835 • service@tersano.com

iClean® FLO3

iClean ${\rm FLO_3}$ is ready to use after water and electrical connection configured.



Trou	hlas	:hac	tina

Troubleshooting				
Indicator Light	Possible Cause	Solution		
All indicator lights off Water outlet does not produce solution	Power is not connected Power adapter is faulty Equipment Failure	Check if power plug is looseReplace power adapterCall service		
All indicator lights off Water outlet produces solution	Indicator light fault	Call service		
No water from the water outlet	Outlet water flow is blocked No water supply to the inlet Blockage inside device	 Replace sediment filter Ensure inlet pipe connected Ensure water source to inlet correct Call service 		
Power light on Operation light off Water flow is nominal	The flow meter does not work	Call Service		
Blue light off	Flow rate too low	Increase flow rate to minimum of 1L/min		
Continuous Green: Standby Flashing Green Light: Water inflow exceeds maximum value of machine Continuous Blue: Working Continuous Red: Call Service		Replace sediment filter every 3-6 months (average). Refer to instructions in replacement sediment filter package.		

Power indicator (Green Flashing)

Working indicator (Blue On)

Water inflow exceeds the maximum value of the machine

(please reduce the water inflow)

tersano®

For more information, contact tersano: (800).727.8835 • service@tersano.com